



Portable Generators

Portable generators are designed to be connected only to selected appliances or lamps. These generators never should be connected directly to a building's wiring system.

- Before starting your generator, carefully read and follow all of the manufacturer's instructions.
- Be sure that the total electric load on your generator will not exceed the manufacturer's rating.
- Always locate your generator where its exhaust will vent safely.
- Prioritize your needs. Use the lowest wattage light bulbs that provide a safe level of light, reserving power for additional lighting elsewhere or a small appliance. Remember that the greater the load on your generator, the more fuel it will use.
- Keep cords out of the way so they don't present a tripping hazard—especially in dimly lit doorways or halls. Never run cords under rugs or carpets where heat might build up or damage to a cord may go unnoticed.
- Extension cords must be properly sized to carry the electric load. Overloaded cords can overheat and cause fires or damage to equipment.

<http://www.pge.com/en/safety/gaselectricsafety/electricgenerator/index.page>